


1973-06 Chevy - GMC Truck Catalog

Roof to Road Solutions to Control Automotive Noise, Vibration and Heat

- Reduce Road Noise
- Reduce Exhaust Harmonics
- Eliminate Mechanical Noise
- Stop Body Panel Vibration
- Reduce Radiated & Reflected Heat
- Stop Audio System Vibration

Pre-Cut Ready to Install Kits Year • Make • Model Specific

The Coolest Cars Have QuietRIDE Inside!™



Order On-line

Everything in One Box to Do the Job Right!

Pre-Cut, Ready To install Kits are Year, Make and Model Specific and include:

- Dynamat Xtreme
- Heat Shield Barrier Insulation
- Spray Adhesive •Seam Tape
- Illustrated Instructions



QuietRIDESolutions®

Phone: 209-942-4777

Fax: 209-942-4476

6507 Pacific Ave. Ste.#334, Stockton,

For more information contact us at: info@quietride.com

©2003-12 •Prices Subject to Change Without Notice



1973-06 Chevy Truck

AcoustiSHIELD™ Pre Cut Kits Ready to Install

Roof to Road Solutions to Control Automotive Noise, Vibration and Heat

Introducing a multi-stage, automotive insulation and sound damping system to give Chevy trucks the “quiet riding comfort” found in today’s new cars. AcoustiSHIELD kits are designed on current “state-of-the-art” auto acoustic technology, to insulate and control the noise, vibration and heat in the passenger cabin. Kits are pre-cut and come with easy-to-follow installation instructions-----everything you need to do the job right.




Turn Your Chevy Truck into “Quiet Riding Comfort”

Stage 1 Sound Damper Pads



The first stage consists of pre-trimmed, self-adhesive, Sound Damper Pads, bonded to strategically located trouble spots on the floor pan and roof of the vehicle to control body panel vibration and noise. These spots are mapped and labeled in detailed instructions which are included in the kit.

Stage 2 Heat Absorber/Barrier Panels



The second stage uses a high-tech absorber/barrier material, bonded to the body panels, to both sound deaden and insulate the vehicle from radiant heat penetration from the engine and road. Each absorber panel is cut to the correct shape and contour and is mapped and labeled in the detailed instructions.

Kits Include:

- **Stage 1** Pre-Sized Sound Damper Pads
- **Stage 2** Pre-Trimmed Heat Absorber / Barrier Panels, Spray Adhesive and Sealing Tape
- **Complete Illustrated Installation Instruction**

Dealer program available. For more information contact us at info@quietride.com

©2003-12 Quiet Ride Solutions Prices Subject to Change Without Notice



Phone: 209-942-4777

Fax: 209-942-4476

6507 Pacific Ave. Ste.#334, Stockton,



Product Application Codes and Price Sheet

1973-79 Series Trucks

CHEV 7379-TAK	1973-79 Chevy Truck Complete Kit	385
CHEV 7379-TCK	1973-79 Chevy Truck Cowl Kit	93
CHEV 7379-TFK	1973-79 Chevy Truck Floor Kit	164
CHEV 7379-TRCK	1973-79 Chevy Truck Rear Cab Kit	93
ASU-DDBIK-2	Universal 4 Door Damper Kit	52

Other Parts For This Vehicle (Sold Separately)

CHEV 7379-TRCC	1973-79 Chevy Truck Rear Cab Cover	180
CHEV 7379-T	1973-79 Chevy Truck Firewall	166
CHEV 7379-K20-T	1973-79 Chevrolet/GMC K20 Firewall	166

1973-91 Chevy/GMC Blazer

CHEV 7391-BLZAK	1973-1991 Chevy Blazer Complete Kit	752
CHEV 7391-BLZBPK	1973-1991 Chevy Blazer Body Panel Kit	175
CHEV 7391-BLZCK	1973-1991 Chevy Blazer Cowl Kit	93
CHEV 7391-BLZFK	1973-1991 Chevy Blazer Front Floor Kit	164
CHEV 7391-BLZRFBK	1973-1991 Chevy Blazer Rear Floor Kit	128
CHEV 7391-BLZRK	1973-1991 Chevy Blazer Roof Kit	175
ASU-DDBIK-2	Universal 4 Door Damper Kit	52

Other Parts For This Vehicle (Sold Separately)

CHEV 7379-T	1973-79 Chevy Truck Firewall	166
CHEV 7379-K20-T	1973-79 Chevrolet/GMC K20 Firewall	166
CHEV 7391-BLZRHK	1973-1991 Chevy Blazer Rear Headliner Cover	152
CHEV 8087-T	1980-1987 Chevy Truck Firewall	166

1980-87 Series Trucks

CHEV 8087-TAK	1980-1987 Chevy Truck Complete Kit	385
CHEV 8087-TCK	1980-1987 Chevy Truck Cowl Kit	93
CHEV 8087-TFK	1980-1986 Chevy Truck Floor Kit	164
CHEV 8087-TRCK	1980-1987 Chevy Truck Rear Cab Kit	93
ASU-DDBIK-2	Universal 4 Door Damper Kit	52

1980-87 Suburban

CHEV 8087-SUBAK	1980-1987 Chevy Suburban Complete Kit	879
CHEV 8087-SUBBPK	1980-1987 Chevy Suburban Body Panel Kit	152
CHEV 8087-SUBCK	1980-1987 Chevy Suburban Cowl Kit	93
CHEV 8087-SUBDK	1980-1987 Chevy Suburban 4-Door Damper Barrier Shield Kit	104
CHEV 8087-SUBFK	1980-1987 Chevy Suburban Front Floor Kit	164
CHEV 8087-SUBRFK	1980-1987 Chevy Suburban Rear Floor Kit	129
CHEV 8087-SUBRK	1980-1987 Chevy Suburban Roof Kit	199

Other Parts For This Vehicle (Sold Separately)

CHEV 8898-TRCC	1988-1998 Chevy Truck Rear Cab Cover/Tray	180
CHEV 8091-THK	1980-1991 Chevy Truck Headliner	166
CHEV 8087-T	1980-1987 Chevy Truck Firewall	166

1988-98 Series Trucks

CHEV 8898-TAK	1988-1998 Chevy Truck Complete Kit	435
CHEV 8898-TCK	1988-1998 Chevy Truck Cowl Kit	52
CHEV 8898-TFK	1988-1998 Chevy Truck Floor Kit	164
CHEV 8898-TRCK	1988-1998 Chevy Truck Rear Cab Kit	93
CHEV 8898-TRK	1988-1998 Chevy Truck Roof Kit	93
ASU-DDBIK-2	Universal 4 Door Damper Kit	52

Other Parts For This Vehicle (Sold Separately)

CHEV 8898-TRCC	1988-1998 Chevy Truck Rear Cab Cover/Tray	180
CHEV 8091-THK	1980-1991 Chevy Truck Headliner	166

1999-2006 Series Trucks

CHEV 9906-TAK	1999-2006 Chevy Truck Reg Cab Complete Kit	346
CHEV 9906-TCK	1999-2006 Chevy Truck Reg Cab Cowl Kit	52
CHEV 9906-TFK	1999-2006 Chevy Truck Reg Cab Floor Kit	164
CHEV 9906-TRCK	1999-2006 Chevy Truck Reg Cab Rear Cab Kit	93
ASU-DDBIK-2	Universal 4 Door Damper Kit	52

1999-2006 Truck (Extended Cab)

CHEV 9906-XTAK	1999-2006 Chevy Truck Ext. Cab Complete Kit	416
CHEV 9906-XTCK	1999-2006 Chevy Truck Ext. Cab Cowl Kit	52
CHEV 9906-XTFK	1999-2006 Chevy Truck Ext. Cab Floor Kit	202
CHEV 9906-XTRCK	1999-2006 Chevy Truck Ext. Cab Rear Cab Kit	128
ASU-DDBIK-2	Universal 4 Door Damper Kit	52

1999-2006 Truck (Crew Cab)

CHEV 9906-CCTAK	1999-2006 Chevy Truck Crew Cab Complete Kit	473
CHEV 9906-CCTCK	1999-2006 Chevy Truck Crew Cab Cowl Kit	52
CHEV 9906-CCTFK	1999-2006 Chevy Truck Crew Cab Floor Kit	245
CHEV 9906-CCTRCK	1999-2006 Chevy Truck Crew Cab Rear Cab Kit	93
ASU-DDBIK-4	Universal 2 Door Damper Kit	104

Firewall Mounting Pin Options For Older Cars and Trucks

American Cars and Trucks used a wide variety of mounting pins, clips, buttons and screws to attach the firewall insulator to the interior of the steel firewall bulkhead. Clean up and reuse your original mounting pins if you have them. We offer the following mounting pins and information based on what we have been able to find available.

Early Ford Firewall Mounting Pins

These all steel firewall mounting pins are a reproduction of the originals. They are available in a 3/4 inch length (Long) and in a 1/2 inch length (Short). The long pins work best for the early production cars and trucks. The Short pin works best for the 1942-48 cars and 1940-47 Trucks. The long pins may have been used in Ford cars as late as 1954. The short pins may have been used in Ford Trucks through the mid 1950s.

- Ford 3541-MPL 1935-41 Ford Firewall Mounting Pin-Long \$3**
- Ford 4147-MPS 1941-47 Ford Firewall Mounting Pin-Short \$3**



GM Firewall Mounting Plugs

General Motors started using a plastic firewall mounting plug to attach the insulator in the mid 1950s--1955 for Trucks and 1957 for Cars. These plugs are still used in GM vehicles today.

- GM 5500-MP 1955 to Present General Motors Mounting Plug \$3**



Street Rod Mounting Pins

With this new mounting pin kit, you can weld up your firewall mounting holes and install any of our insulators for that "smoothie look." Kit includes nine pin-sets and installation instructions.

- SRMP Street Rod Firewall Mounting Pin Kit \$34**



Universal Mounting Pins

If your original firewall mounting pins are missing or damaged beyond repair, these universal pins may be a solution. They are a plastic "Christmas tree" type pin that will fit most 5/16 inch holes. Kit includes 10 pins.

- UMPS-10 Universal Mounting Pin Set \$20**



Universal Wire Cap

A variety of car and truck manufacturers in the 1930s used a wire cap retainer to mount the firewall insulator. These are still available in a Long (1/2 inch) and Short (1/4 inch) variety and have a 1/2 inch button head that can be painted. To match the firewall color.

- UWC-MPL Universal Wire Cap Mounting Pin Long \$1**
- UWC-MPS Universal Wire Cap Mounting Pin Short \$1**

