

Roof to Road Solutions to Control Automotive Noise, Vibration and Heat

- Reduce Road Noise
- Reduce Exhaust Harmonics
- Eliminate Mechanical Noise
- Stop Body Panel Vibration
- Reduce Radiated & Reflected Heat
- Stop Audio System Vibration

Pre-Cut Ready to Install Kits Year • Make • Model Specific

The Coolest Cars Have QuietRIDE Inside!™

Firewall Insulator

Fits under dash against the firewall bulkhead.

Roof Kit

Roof & Quarter Panels above beltline.

Body Panel Kit

All Panels below the beltline including Package Tray, Seat Divider, Rear Wheel Wells, Fenders, Rear Quarters and Tail Panels

Door Kit

All Doors

Floor Kit

Front Floor, Rear Floor, Transmission Hump/ Driveline

Cowl Kit

Panels between the firewall and front door of the vehicle.

Trunk Floor Kit

Trunk Floor & Tire Well



Order On-line

Everything in One Box to Do the Job Right!
Pre-Cut, Ready To install Kits are Year, Make and Model Specific and include:

- Dynamat Xtreme
- Heat Shield Barrier Insulation
- Spray Adhesive •Seam Tape
- Illustrated Instructions



QuietRIDE Solutions®

Phone: 209-942-4777

Fax: 209-942-4476

6507 Pacific Ave. Ste.#334, Stockton, CA 95207

For more information contact us at: info@quietride.com




QuietRIDE Solutions

Corvair Cars

AcoustiSHIELD™ Pre Cut Kits Ready to Install

Roof to Road Solutions to Control Automotive Noise, Vibration and Heat

Introducing a multi-stage, automotive insulation and sound damping system to give Corvair cars the “quiet riding comfort” found in today’s new cars. AcoustiSHIELD kits are designed on current “state-of-the-art” auto acoustic technology, to insulate and control the noise, vibration and heat in the passenger cabin. Kits are pre-cut and come with easy-to-follow installation instructions-----everything you need to do the job right.



Duke Edwards

Turn Your Corvair into “Quiet Riding Comfort”

Stage 1 Sound Damper Pads



The first stage consists of pre-trimmed, self-adhesive, Sound Damper Pads, bonded to strategically located trouble spots on the floor pan and roof of the vehicle to control body panel vibration and noise. These spots are mapped and labeled in detailed instructions which are included in the kit.

Stage 2 Heat Absorber/Barrier Panels



The second stage uses a high-tech absorber/barrier material, bonded to the body panels, to both sound deaden and insulate the vehicle from radiant heat penetration from the engine and road. Each absorber panel is cut to the correct shape and contour and is mapped and labeled in the detailed instructions.

Kits Include:

- **Stage 1** Pre-Sized Sound Damper Pads
- **Stage 2** Pre-Trimmed Heat Absorber / Barrier Panels, Spray Adhesive and Sealing Tape
- **Complete Illustrated Installation Instruction**

Dealer program available. For more information contact us at info@quietride.com

©2003-12 Quiet Ride Solutions Prices Subject to Change Without Notice



Phone: 209-942-4777

Fax: 209-942-4476

6507 Pacific Ave. Ste.#334, Stockton,



Corvair Cars

AcoustiSHIELD™

Pre Cut Kits Ready to Install

Product Application Codes and Price Sheet

Inventory #	Description	Price	Inventory #	Description	Price
1960-64 Corvair Coupe			1965-69 Corvair Coupe		
CORVR 6064-CAK	1960-1964 Corvair Coupe Complete Kit	551	CORVR 6569-CAK	1965-1969 Corvair Coupe Complete Kit	551
CORVR 6064-CBPK	1960-1964 Corvair Coupe Body Panel Kit	117	CORVR 6569-CBPK	1965-1969 Corvair Coupe Complete Kit	117
CORVR 6064-CCK	1960-1964 Corvair Coupe Cowl/Dash Kit	93	CORVR 6569-CCK	1965-1969 Corvair Coupe Cowl/Dash Kit	93
CORVR 6064-CFK	1960-1964 Corvair Coupe Floor Kit	199	CORVR 6569-CFK	1965-1969 Corvair Coupe Floor Kit	199
CORVR 6064-CRK	1960-1964 Corvair Coupe Roof Kit	117	CORVR 6569-CRK	1965-1969 Corvair Coupe Roof Kit	117
ASU-DDBIK-2	Universal 4 Door Damper Kit	52	ASU-DDBIK-2	Universal 4 Door Damper Kit	52

1960-64 Corvair Sedan

CORVR 6064-SAK	1960-1964 Corvair Sedan Complete Kit	578
CORVR 6064-SBPK	1960-1964 Corvair Sedan Body Panel Kit	93
CORVR 6064-SCK	1960-1964 Corvair Sedan Cowl/Dash Kit	93
CORVR 6064-SFK	1960-1964 Corvair Sedan Floor Kit	199
CORVR 6064-SRK	1960-1964 Corvair Sedan Roof Kit	117
ASU-DDBIK-4	Universal 2 Door Damper Kit	104

1965-69 Corvair Sedan

CORVR 6569-SAK	1965-1969 Corvair Sedan Complete Kit	578
CORVR 6569-SBPK	1965-1969 Corvair Sedan Body Panel Kit	93
CORVR 6569-SCK	1965-1969 Corvair Sedan Cowl/Dash Kit	93
CORVR 6569-SFK	1965-1969 Corvair Sedan Floor Kit	199
CORVR 6569-SRK	1965-1969 Corvair Sedan Roof Kit	117
ASU-DDBIK-4	Universal 2 Door Damper Kit	104

1960-64 Corvair Convertible

CORVR 6064-CVAK	1960-1964 Corvair Convert Complete Kit	441
CORVR 6064-CVBPK	1960-1964 Corvair Convert Body Panel Kit	117
CORVR 6064-CVCK	1960-1964 Corvair Convert Cowl/Dash Kit	93
CORVR 6064-CVFK	1960-1964 Corvair Convert Floor Kit	199
ASU-DDBIK-2	Universal 4 Door Damper Kit	52

1965-69 Corvair Convertible

CORVR 6569-CVAK	1965-1969 Corvair Convert Complete Kit	441
CORVR 6569-CVBPK	1965-1969 Corvair Convert Body Panel Kit	117
CORVR 6569-CVCK	1965-1969 Corvair Convert Cowl/Dash Kit	93
CORVR 6569-CVFK	1965-1969 Corvair Convert Floor Kit	199
ASU-DDBIK-2	Universal 4 Door Damper Kit	52

Other Parts Available for this Car (Sold Separately)

CORVR 6064-HDK	1960-1964 Corvair Hood-Deck Kit	79
----------------	---------------------------------	----

Other Parts Available for this Car (Sold Separately)

CORVR 6569-EB	1965-1969 Corvair Engine Bay Kit	117
CORVR 6569-HDK	1965-1969 Corvair Hood Kit	79

Typical Patterns For the Corvair Cars.



Floor Kit



Cowl Kit



Body Panel Kit

Engine Bay Kit



Roof Kit

Insulation panels are not visible when properly installed behind upholstery panels and under carpets.



Firewall Mounting Pin Options For Older Cars and Trucks

American Cars and Trucks used a wide variety of mounting pins, clips, buttons and screws to attach the firewall insulator to the interior of the steel firewall bulkhead. Clean up and reuse your original mounting pins if you have them. We offer the following mounting pins and information based on what we have been able to find available.

Early Ford Firewall Mounting Pins

These all steel firewall mounting pins are a reproduction of the originals. They are available in a 3/4 inch length (Long) and in a 1/2 inch length (Short). The long pins work best for the early production cars and trucks. The Short pin works best for the 1942-48 cars and 1940-47 Trucks. The long pins may have been used in Ford cars as late as 1954. The short pins may have been used in Ford Trucks through the mid 1950s.



- Ford 3541-MPL 1935-41 Ford Firewall Mounting Pin-Long \$3**
- Ford 4147-MPS 1941-47 Ford Firewall Mounting Pin-Short \$3**

GM Firewall Mounting Plugs

General Motors started using a plastic firewall mounting plug to attach the insulator in the mid 1950s--1955 for Trucks and 1957 for Cars. These plugs are still used in GM vehicles today.



- GM 5500-MP 1955 to Present General Motors Mounting Plug \$3**

Street Rod Mounting Pins

With this new mounting pin kit, you can weld up your firewall mounting holes and install any of our insulators for that "smoothie look." Kit includes nine pin-sets and installation instructions.



- SRMP Street Rod Firewall Mounting Pin Kit \$34**

Universal Mounting Pins

If your original firewall mounting pins are missing or damaged beyond repair, these universal pins may be a solution. They are a plastic "Christmas tree" type pin that will fit most 5/16 inch holes. Kit includes 10 pins.



- UMPS-10 Universal Mounting Pin Set \$20**

Universal Wire Cap

A variety of car and truck manufacturers in the 1930s used a wire cap retainer to mount the firewall insulator. These are still available in a Long (1/2 inch) and Short (1/4 inch) variety and have a 1/2 inch button head that can be painted. To match the firewall color.



- UWC-MPL Universal Wire Cap Mounting Pin Long \$1**
- UWC-MPS Universal Wire Cap Mounting Pin Short \$1**